

Preform Eccentricity Tester



Digital Dial Gauge

Model No. PET - 0110

Preform Eccentricity Tester is a consistent tool that helps the manufacturer in testing the eccentricity of PET preforms. It is based on the principle that how a preform deviates from being circular.

- Easy and accurate operations
- Comes with Zero Tolerance
- Revolving type equipment
- Repeatability in test measurements of preforms with Preform Eccentricity Tester, PET Preform Eccentricity is checked as the shape, size and quality of product on its eccentricity.

Key Specifications:

Range	0 – 10 mm
Least count	0.001 mm
Display	LCD (Digital)
Preform Holder Diameter	As per requirement (Single holder part of supply)

Highlights:

Gauge	1
Dimensions	310 x 100 x 275 mm
Stand	Magnetic adjustable arm stand

** Various size Preform Holder Diameter options available on requirement.

Comes with height adjusting knob to adjust the height of gauge and preform holder. Highly accurate and reliable instrument to measure the eccentricity of preforms.

Optional:

Preform holder different dia meter available on request.

Thank you customers for choosing us as your partners in growth !



*All the above logos are the sole property of their respective owners and are used purely for depiction purposes only.

OUR OTHER PRODUCTS :-



Head Office : Presto Stantest Private Limited

I-42, DLF Industrial Area Phase-I, Delhi Mathura Road, Faridabad 121003, Haryana, India
 P : +91 129 4272727 E : info@prestogroup.com

Branches :

Mumbai
 503-504B, Fair link Centre, Opp. Fame Adlab
 Behind Mongini's Off Link Road
 Andheri (West), Mumbai 400058
 P : +91 022 42957052, 42957053
 E : west@prestogroup.com

Kolkata
 93, 3rd Floor, Karnani Estate
 209, A.J.C. Bose Road
 Kolkata-700017. West Bengal
 P : +91 033 40612012
 E : east@prestogroup.com

Chennai
 A-3, First Floor, Sri Sathya Sai Building
 755, Poonamallee High Road, Kilpauk
 Chennai- 600 010. Tamil Nadu
 P : +91 044 43865260, 43838372
 E : south@prestogroup.com

